


EcoCut 1270

CERAMIC TILE CUTTER




1270mm

Art. No. 010495




HEKA
Qualitätswerkzeuge GmbH








The fore ruler which is disassembled is fixed to the nuts located on the body with bolt as shown.




Likewise the side ruler and side guide which are disassembled are mounted on the channels on the side of the body.




90° ADJUSTMENT: Adjust the dimension you want to cut by means of the sliding angle on the ruler and fix the bolt through the hole number 2 as shown.



45° ADJUSTMENT: Adjust the dimension you want to cut by means of sliding angle on the ruler and fix the bolt through the channel number 3 as shown. When the bolt rests on the end of the channel, 45° is obtained.



CUTTING: Score the cutting wheel once on ceramic tile by means of sliding arm.



BREAKING: Press the sliding arm downwards slightly.